



3M COLDSHRINK QS III INLINE SPLICING KIT 95-AC645-1-240/C & 95-AC645-1-400/C

WITH COLDSHRINK JACKETING TUBE SUITABLE FOR
120 TO 400 mm² POLYMERIC SINGLE CORE CABLE WITH
COPPER WIRE SCREEN ACC. TO IEC 60840 26/45 kV

KIT REF.	95-AC645-1-240/C	95-AC645-1-400/C
DIAMETER OVER CABLE JACKET MAX. (mm.)	69.0	69.0
DIAMETER OVER PRIMARY INSULATION 'E' (mm.)	31.5 – 53.0	31.5 – 53.0
CROSS SECTION (mm. ²)	120 – 240	300 – 400
DIAMETER OVER CONNECTOR (mm.)*	22.1 – 53.0	22.1 – 53.0
CONNECTOR LENGTH MAX. (mm.)	210	210

* IMPORTANT CONNECTOR INFORMATION

FOR CONNECTORS BELOW 27.2mm. IN DIAMETER AN ADAPTOR TUBE
MUST BE INSTALLED OVER THE CENTRE OF THE CONNECTOR.

IMPORTANT NOTICE

CROSS SECTIONAL AREA IS STATED AS A GUIDE ONLY. PLEASE SELECT
THE KIT BASED UPON THE PRIMARY INSULATION DIAMETER OF THE CABLE,
ALSO TAKING INTO ACCOUNT THE CHOSEN CONNECTOR DIMENSIONS.

3M UNITED KINGDOM PLC © 2007 3M CENTRE, CAIN ROAD, BRACKNELL BERKS. RG12 8HT, ENGLAND	3	LATEST REQUIREMENT.	ERH	04.04.12
	2	LATEST REQUIREMENT.	ERH	06.05.09
	1	RELEASED.	ERH	22.06.07
	ISSUE	DESCRIPTION / ECO	BY	DATE
ALL STATEMENTS, TECHNICAL INFORMATION AND RECOMMENDATIONS CONTAINED HEREIN ARE BASED ON TESTS WE BELIEVE TO BE RELIABLE. HOWEVER, SINCE THE CONDITIONS OF USE AND THE APPLICATION ARE BEYOND OUR CONTROL, THE PURCHASER IS RESPONSIBLE FOR THE PERFORMANCE OF THE JOINTS AND TERMINATIONS MADE IN CONNECTION WITH THE USE OF DATA OR SUGGESTIONS STATED HEREIN.	3M COLDSHRINK QSIII INLINE SPLICING KIT 95-AC645-1-240/C & 95-AC645-1-400/C WITH COLDSHRINK JACKETING TUBE SUITABLE FOR 120 – 400 mm ² POLYMERIC SINGLE CORE CABLE WITH Cu WIRE SCREEN-INSTALLATION INSTRUCTIONS			
Drawn : E.REES-HAYWARD	Des.Eng: A.RUSSELL			
Cad File: XE-0091-3148-5	Checked:			
3M ELECTRICAL PRODUCTS	AA-BBCC-5770-5	XE-0091-3148-5	SHEET 1 OF 6	A4



THORNE &
DERRICK
INTERNATIONAL

WWW.CABLEJOINTS.CO.UK
THORNE & DERRICK UK
TEL 0044 191 490 1547 FAX 0044 477 5371
TEL 0044 117 977 4647 FAX 0044 977 5582

BEFORE STARTING:-

CHECK TO ENSURE THAT THE KIT YOU ARE GOING TO USE FITS THE CABLE.

REFER TO THE KIT LABEL AND THE TITLE OF THE INSTALLATION INSTRUCTION.

COMPONENTS OR WORKING STEPS MAY HAVE BEEN UPDATED SINCE YOU LAST INSTALLED THIS

PRODUCT. CHECK KIT CONTENTS FOR ANY MISSING COMPONENTS. REPORT ALL MISSING

ITEMS. DO NOT START WITH INCOMPLETE MATERIALS.

CAREFULLY READ AND FOLLOW THE STEPS IN THE INSTALLATION INSTRUCTION.

GENERAL INSTRUCTIONS:-

IF A SOLVENT IS USED FOLLOW THE MANUFACTURER'S INSTRUCTIONS.

KEEP THE WORK AREA CLEAN AND TIDY.



THORNE &
DERRICK
INTERNATIONAL

WWW.CABLEJOINTS.CO.UK
THORNE & DERRICK UK
TEL 0044 191 490 1547 FAX 0044 477 5371
TEL 0044 117 977 4647 FAX 0044 977 5582



ELECTRICAL PRODUCTS


AA-BBCC-5770-5

XE-0091-3148-5

SHEET
2 of 6


ISS. 3

FIG.1



1.1 SET CABLES INTO POSITION AND ENSURE OVERLAP. REMOVE CABLE SHEATHS AS FIG.1. CLEAN AND ABRAID CABLE SHEATH FOR A FURTHER 250mm.

FIG.2



2.1 CUT CORES TO LENGTH AS PER FIG.2.

2.2 CAREFULLY BEND BACK COPPER SCREEN WIRES ON TO CABLE SHEATH AND SECURE WITH PVC TAPE.


2.3 PARK COLD SHRINK 'FOLD BACK' RE-JACKETING TUBE ON TO CABLE 1.

2.4 REMOVE BONDED SEMI-CONDUCTING LAYER TO DIMENSIONS AS PER FIG.2.

2.5 REMOVE PRIMARY INSULATION FOR INTERNAL DEPTH OF CONNECTOR PLUS 5mm.

NOTE: ALL DIMENSIONS ARE TO THE "CENTRE OF THE JOINT". WHERE SPLIT AND/OR BLOCKED CONNECTORS ARE USED THE DIMENSIONS OF THE BLOCK IN THE CONNECTOR MUST BE TAKEN INTO ACCOUNT.


FIG.3



3.1 POSITION THE JOINT BODY ON TO CABLE ②.

NOTE: FOR CONNECTORS BELOW 27.2mm IN DIAMETER, PARK ADAPTOR TUBE ON CORE AT THIS POINT.


FIG.4



- 4.1 CLEAN ALL INSULATION ONLY IN THE DIRECTION SHOWN.
- 4.2 INSTALL THE CONNECTOR ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS. CLEAN, DEBURR AND DEGREASE THE CONNECTOR.
- 4.3 APPLY A MARKING TAPE ON THE CABLE JACKET 400mm. FROM THE CENTRE OF THE CONNECTOR.
- 4.4 APPLY P55/1 GREASE OVER THE SEMI-CONDUCTIVE SCREENS, THE PRIMARY INSULATION AND THE CONNECTOR USING THE PLASTIC GLOVE PROVIDED.

NOTE: FOR CONNECTORS BELOW 27.2mm IN DIAMETER, INSTALL ADAPTOR TUBE OVER THE CENTRE OF THE CONNECTOR AT THIS POINT.

FIG.5




- 5.1 SLIDE THE JOINT BODY OVER THE CONNECTION UNTIL POSITION 'A'.
- 5.2 USING POSITION 'A' AS A STARTING POINT, SHRINK THE BODY ON TO THE CORE BY UNWINDING THE SPIRAL. ONCE THE BODY HAS BEEN SHRUNK PAST ITS CENTRE MARK, AND BEFORE IT HAS BEEN SHRUNK FULLY ACROSS THE CONNECTOR, ENSURE THE BODY IS IN POSITION USING THE PVC TAPE AND CENTRE MARK. IF NOT CORRECTLY POSITIONED, MAKE CORRECTION BY DISPLACEMENT.

**** PLEASE NOTE: THE SYMMETRICAL POSITION OF THE JOINT BODY IS CRITICAL. ****


- 5.3 REMOVE MARKING TAPE.

FIG.6



- 6.1 APPLY ONE HALF-LAPPED LAYER OF 50mm WIDE COPPER SCREEN TAPE OVER THE SPLICE BODY.


FIG.7



7.1 LAY THE WIRES NEATLY ACROSS THE JOINT AND CONNECT IN THE OVERSTRIP AREA USING THE SUPPLIED CONNECTOR.

7.2 APPLY ONE HALF-LAPPED LAYER OF 2228 TAPE OVER THE CONNECTOR.

FIG.8



8.1 OVERTAPE JOINT AND COPPER SCREEN WIRES WITH ANOTHER HALF LAPPED LAYER OF 50mm WIDE COPPER SCREEN TAPE.


8.2 WRAP THE SCOTCH® 2228 TAPE, STARTING 100mm ON THE CABLE SHEATH AND OVER THE COPPER SCREEN TAPE UP ON TO THE JOINT BODY ACCORDING TO ILLUSTRATION. ENSURE MINIMUM DIAMETER 50mm OVER THE SCOTCH® 2228 TAPE JOINT.



**THORNE &
DERRICK
INTERNATIONAL**


WWW.CABLEJOINTS.CO.UK
THORNE & DERRICK UK
TEL 0044 191 490 1547 FAX 0044 477 5371
TEL 0044 117 977 4647 FAX 0044 977 5582

FIG.9



- 9.1 BEGIN TO INSTALL THE OUTER PROTECTION COLD SHRINK TUBE 50mm BEYOND THE END OF THE FIRST 2228 TAPE, (AT THE OPPOSITE END TO THE SCREEN CONNECTOR), AND SLOWLY PULLING AND UNWINDING THE INNER CORE COUNTERCLOCKWISE TOWARD THE JOINT BODY. THE OUTER CORE SHOULD REMAIN RELATIVELY STATIONARY WHILE UNWINDING THE INNER CORE. IF THE OUTER CORE BEGINS TO MOVE TOWARDS THE FIRST 2228 TAPE SEAL, GENTLY PULL THE OUTER CORE AND PROTECTION TUBE TOWARDS THE SECOND 2228 TAPE AND CONTINUE UNWINDING THE INNER CORE.

FIG.10



- 10.1 CONTINUE TO INSTALL THE COLD SHRINK TUBE OVER THE SECOND 2228 TAPE SEAL ON THE OTHER SIDE OF THE JOINT BY SLOWLY PULLING AND UNWINDING THE OUTER CORE COUNTER CLOCKWISE. THIS PORTION OF THE COLD SHRINK TUBE INSTALLS DIFFERENTLY THAN TYPICAL COLD SHRINK PRODUCTS IN THAT AS THE TUBE SHRINKS, THE END ROLLS UNDER. THE TUBE MIGHT NEED A SLIGHT PUSH TO GET OVER THE SECOND 2228 TAPE SEAL.