




**Clifford & Snell**

# Wiring Diagrams




## TYPICAL CONNECTION DIAGRAMS FOR YODALEX STANDARD TEMP. EXPLOSION PROOF SOUNDER


### MODEL YO9

For other options and full operating and installation instructions see website [www.cliffordandsnell.com](http://www.cliffordandsnell.com)

#### AC ALARM CONNECTIONS AND SOUND SIGNAL SELECTION




#### DC ALARM CONNECTION AND SOUND SIGNAL SELECTION




## TYPICAL CONNECTION DIAGRAMS FOR MANUAL CALL POINTS

### MODELS: - BREAK GLASS, PUSH BUTTON


NORMALLY OPEN WITH SERIES MONITORING




INTERNAL SWITCH CONNECTIONS ARMED



NORMALLY OPEN



NORMALLY CLOSED



The Call Point is supplied in two versions: - supplied with or without a monitoring resistor. The version with the monitoring resistor should be connected as shown above. Check panel instructions to ensure the correct value resistor is fitted.

If not required, remove and connect as shown in 'A' or 'B'.

Ratings: - Vac: 250V max. / 12 V min. Imax: 5A resistive. Vdc: 30V max. / 12V min.  
Contact resistance: 50 millioms max. Conductor size: 2.5 sq.mm max. per terminal.

When supplied without the monitoring resistor the Call Point should be connected as shown in 'A' or 'B' above.