



CRE1 - Cable to Rebar



A mm	B mm ²	Weld Powder	Mould	Handle Clamp
10 - 40	16	WEP 045	CRE1-A-16	HCA 001
	25		CRE1-A-25	
	35		CRE1-A-35	
	8mm Ø	WEP 090	CRE1-C-8SC	HCC 004
	50		CRE1-C-50	
	70		CRE1-C-70	
	95		CRE1-C-95	
	120		CRE1-C-120	
	150	WEP 150	CRE1-C-150	HCD 004
	185	WEP 250	CRE1-C-185	
	240	2 x WEP 150	CRE1-D-240	
	300		CRE1-D-300	

To safely and effectively weld cable to rebar some form of mould packing must be used. Preformed ceramic fibre packing (part no. PAK001) or Duxseal (Part no. DXS001) can be used for this purpose.

CRE2 - Cable to Rebar



A mm	B mm ²	Weld Powder	Mould	Handle Clamp				
16	16	WEP 090	CRE2-C-16R16	HCC 001				
	25		CRE2-C-16R25					
	35		CRE2-C-16R35					
	50	WEP 115	CRE2-C-16R50		HCC 001			
	8mm Ø		CRE2-C-16R8SC					
	70	WEP 115	CRE2-C-16R70					
	95	WEP 150	CRE2-C-16R95			HCC 001		
	120		CRE2-C-16R120					
	150	WEP 200	CRE2-C-16R150				HCC 001	
	185		CRE2-C-16R185					
	240	WEP 250	CRE2-C-16R240					HCD 001
	300	2 x WEP 150	CRE2-D-16R300					
20	16	WEP 115	CRE2-C-20R16	HCC 001				
	25		CRE2-C-20R25					
	35		CRE2-C-20R35					
	50	WEP 150	CRE2-C-20R50		HCC 001			
	8mm Ø		CRE2-C-20R8SC					
	70	WEP 150	CRE2-C-20R70					
	95	WEP 200	CRE2-C-20R95			HCC 001		
	120		CRE2-C-20R120					
	150	WEP 200	CRE2-C-20R150				HCD 001	
	185	WEP 250	CRE2-C-20R185					
	240	2 x WEP 150	CRE2-D-20R240				HCD 001	
	300	2 x WEP 200	CRE2-D-20R300					

Table continued on page 25


To safely and effectively weld cable to rebar some form of mould packing must be used. Preformed ceramic fibre packing (part no. PAK001) or Duxseal (Part no. DXS001) can be used for this purpose.

CABLE JOINTS, CABLE TERMINATIONS, CABLE GLANDS, CABLE CLEATS
FEEDER PILLARS, FUSE LINKS, ARC FLASH, CABLE ROLLERS, CUT-OUTS

CU-NNECT EXOTHERMIC WELDING

CRE2 - Cable to Rebar (continued)


A mm	B mm ²	Weld Powder	Mould	Handle Clamp	
25	16	WEP 200	CRE2-C-25R16	HCC 001	
	25		CRE2-C-25R25		
	35		CRE2-C-25R35		
	50		CRE2-C-25R50		
	8mm Ø		CRE2-C-25R8SC		
	70	WEP 250	CRE2-C-25R70		
	95		CRE2-C-25R95		
	120		CRE2-C-25R120		
	150	2 x WEP 150	CRE2-D-25R150		HCD 001
	185		CRE2-D-25R185		
240	2 x WEP 200	CRE2-D-25R240			
300		CRE2-D-25R300			
30	16	WEP 250	CRE2-C-30R16	HCC 001	
	25		CRE2-C-30R25		
	35		CRE2-C-30R35		
	50	2 x WEP 150	CRE2-D-30R50	HCD 001	
	8mm Ø		CRE2-D-30R8SC		
	70		CRE2-D-30R70		
	95	CRE2-D-30R95			
	120	2 x WEP 200	CRE2-D-30R120		
	150		CRE2-D-30R150		
	185	2 x WEP 250	CRE2-D-30R185		
	240		CRE2-D-30R240		
	300	3 x WEP 200	CRE2-D-30R300		



To safely and effectively weld cable to rebar some form of mould packing must be used. Preformed ceramic fibre packing (part no. PAK001) or Duxseal (Part no. DXS001) can be used for this purpose.

CRE3 - Cable to Rebar

A mm	B mm ²	Weld Powder	Mould	Handle Clamp	
10 - 40	16	WEP 045	CRE3-C-16	HCC 002	
	25		CRE3-C-25		
	35		CRE3-C-35		
	8mm Ø	WEP 090	CRE3-C-8SC		
	50		CRE3-C-50		
	70		CRE3-C-70		
	95		CRE3-C-95		
	120		CRE3-C-120		
	150	WEP 150	CRE3-C-150		HCD 002
	185	WEP 250	CRE3-C-185		
	240	2 x WEP 150	CRE3-D-240		
	300		CRE3-D-300		



To safely and effectively weld cable to rebar some form of mould packing must be used. Preformed ceramic fibre packing (part no. PAK001) or Duxseal (Part no. DXS001) can be used for this purpose.